



USER MANUAL

CORDLESS AIR COMPRESSOR 12V



FERREX®

AFTER SALES SUPPORT

858771

GB

☎ 0 1827 438 013

✉ SERVICE-UK@PROTEL-SERVICE.COM

IE

☎ 0 124 695 20

✉ SERVICE-UK@PROTEL-SERVICE.COM

MODEL: FBT-CAC003

05/2026

3
YEAR WARRANTY

ORIGINAL INSTRUCTION MANUAL

CONTENT

1 General	3
2 Security	3
2.1 Explanation of signal words	3
2.2 Explanation of symbols	3
2.3 General power tool safety warnings	3
2.4 Special safety instructions	5
2.5 Additional safety instructions for batteries and chargers	5
2.6 Intended use	6
3 Scope of delivery	6
4 Product Overview	6
5 Before first use	7
5.1 Check the product and scope of delivery	7
5.2 Basic cleaning	7
6 Operation	7
6.1 Battery	7
6.2 On/Off Trigger	7
6.3 Inflating a car tire	7
6.4 LED work light	8
7 Accessories	8
7.1 Installing / removing an accessory	8
7.2 Needle adapter for (sports) balls 13	8
7.3 Tire valve adapter	8
8 Cleaning and care	8
8.1 Cleaning	8
8.2 Maintenance and care	8
8.3 Storage	8
8.4 Transport	8
9 Technical data	9
10 Waste disposal and recycling	9
10.1 Disposing of the packaging	9
10.2 Disposing of the Product	9
10.3 Battery disposal	9
11 EC-Declaration of conformity	9
12 UK Declaration of Conformity	9
13 Warranty	10
13.1 Warranty conditions	10

1 GENERAL



The user manuals provide useful advice on using your new appliance. They will help you to use all the functions, avoid misunderstandings and prevent damage. Please take the time to read this manual carefully and keep it for future

reference.

Please read all the safety instructions!

This manual contains important information on using and handling the appliance. Keep these operating instructions for future reference. Please pass it on with the appliance if it is handed over to third parties. This manual is available in PDF format at www.ferrex12vpower.com.

2 SECURITY

2.1 EXPLANATION OF SIGNAL WORDS

The following signal words are used in this manual, on the product and/or on the packaging.

DANGER!

- » This signal word indicates a dangerous situation which, if not avoided, will result in death or serious injury.

WARNING!

- » This signal word indicates a dangerous situation which, if not avoided, could result in death or serious injury.

CAUTION!

- » This signal word indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

CAUTION!

- » This signal word indicates a hazardous situation which, if not avoided, could result in property damage.

NOTICE

- » This signal word is a preferred signal word to address tips and practices not related to personal injury.

2.2 EXPLANATION OF SYMBOLS

The following symbols are used in these instructions, on the product or on the packaging.



WARNING - To reduce the risk of injury, read the operating instructions.



Always wear hearing protection. Exposure to noise can cause hearing loss.



Do not expose the device to rain. The device must not be operated in rain or under damp or wet conditions. There is a risk of electric shock when wet.



Do not expose the battery to temperatures above 40 °C.



Do not dispose of the battery in a fire. Risk of explosion!



Avoid water contact with the battery. Do not throw the battery into water. Risk of explosion!



Products marked with this symbol fulfil all applicable Community regulations of the European Economic Area.



UKCA stands for: "UK Conformity Assessment". This means "Compliant with UK regulations". With the UKCA mark manufacturer confirms that this unit complies with the applicable UK regulations.



Do not dispose of with household waste!

2.3 GENERAL POWER TOOL SAFETY WARNINGS

WARNING!

- » Improper handling of the product can cause damage.

WARNING!

- » **Read all safety warnings, instructions, illustrations and specifications provided with this power tool.** Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.
- » **Save all warnings and instructions for future reference.**

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

2.3.1 WORK AREA SAFETY

- Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2.3.2 ELECTRICAL SAFETY

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.



- d) **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
- e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f) **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.
- c) **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- e) **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.

2.3.3 PERSONAL SAFETY

- a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- b) **Use personal protective equipment. Always wear eye protection.** Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- c) **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- d) **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- f) **Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
- g) **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
- h) **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** A careless action can cause severe injury within a fraction of a second.
- f) **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
- h) **Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

2.3.5 BATTERY TOOL USE AND CARE

- a) **Recharge only with the charger specified by the manufacturer.** A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- b) **Use power tools only with specifically designated battery packs.** Use of any other battery packs may create a risk of injury and fire.
- c) **When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** Shorting the battery terminals together may cause burns or a fire.
- d) **Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.** Liquid ejected from the battery may cause irritation or burns.
- e) **Do not use a battery pack or tool that is damaged or modified.** Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
- f) **Do not expose a battery pack or tool to fire or excessive temperature.** Exposure to fire or temperature above 130 °C may cause explosion.
- g) **Follow all charging instructions and do not charge the battery pack or tool outside the temperature range specified in the instructions.** Charging improperly or at temperatures outside the specified range may damage the battery and increase the risk of fire..

2.3.4 POWER TOOL USE AND CARE

- a) **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- b) **Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.



2.3.6 SERVICE

- a) **Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.
- b) **Never service damaged battery packs.** Service of battery packs should only be performed by the manufacturer or authorized service providers.

2.4 SPECIAL SAFETY INSTRUCTIONS

- a) **Familiarize yourself with the device.** Please read the operating instructions carefully.
- b) **Inform yourself about the areas of application and the limits of the device, as well as about the specific hazards associated with this device.** Following these instructions can help prevent electric shock, fire, or serious injury.
- c) **Risk of bursting!** When working with the compressed air device, no pressure may be generated that exceeds the specified maximum pressure of the item to be inflated. Do not apply pressure of more than 10.35 bar.
- d) **The device and accessories must not be exposed to rain.** Risk of electric shock! Always store the device and accessories protected indoors.
- e) **Check the device for cracks, small holes, and other defects that may impair safe operation.**
- f) **Do not cut or drill holes into the device.**
- g) **The pressure hose must be free of kinks and obstructions.**
- h) **A tangled or twisted pressure hose can lead to loss of balance or stable footing of the user and may be damaged in the process.**
- i) **The device may only be used for the purpose for which it is designed.** The original design or function of the device must not be modified.
- j) **Always remember: Incorrect or improper use of this device can result in injury to yourself and to others.**
- k) **Never leave the device unattended while the pressure hose is still connected to the item being inflated.**
- l) **The device must not be used if the device itself or the pressure hose is leaking or not functioning properly.**
- m) **Before any adjustment and/or maintenance work on the device, or when the device is not in use, always disconnect the device from the compressed air supply and the power supply.**
- n) **Never carry the device by the pressure hose and never pull on the pressure hose.**
- o) **Always observe the manufacturer's recommended safety instructions for the device, and also follow all other safety instructions for the device.** This can help prevent serious accidents.
- p) **Use of the device is permitted for private use only.**
- q) **Do not use the device for ventilation or breathing purposes.**
- r) **Never direct the compressed air jet directly at people or animals.** Never blow dust or dirt toward yourself or others. This can help prevent serious injuries.

- s) **Protect your lungs.** Always wear a face or dust mask during all work in which dust may be generated. This can help prevent serious injuries.
- t) **This device must not be used to spray chemicals.** Your lungs may be damaged by inhaling toxic gases.
- u) **Always check the device for damaged parts before use.** If a protective device or any other part of the device or accessory is damaged, it must be checked carefully to determine whether the device can still perform its function properly and safely.
- v) **The device must be checked for correct alignment and possible binding of moving parts, as well as for broken parts, the mounting of parts, and any other conditions that may impair the proper and safe operation of the device.** Damaged parts or protective devices must be repaired or replaced by an authorized service centre. This can help prevent electric shock, fire, or serious injury.
- w) **Risk of bursting!** Always closely monitor the item being inflated during inflation.
- x) **To avoid overinflation, a reliable and accurate pressure gauge must be used during inflation.** The pressure gauge on the device provides only a reference value and cannot provide binding information on the exact values.
- y) **Never leave the device unattended during inflation.**
- z) **After 5 (five) minutes of continuous operation, the pressure pump must pause for 5 (five) minutes.**
- aa) **Keep these safety instructions in a safe place.** Read these instructions frequently and pass them on to other persons who may also work with this device.
- ab) **If you lend this device to others, always include these safety instructions.**
- ac) **Do not open the device.** There are no user-serviceable parts.

2.5 ADDITIONAL SAFETY INSTRUCTIONS FOR BATTERIES AND CHARGERS

To avoid malfunctions, damage and health impairments, please observe the attached general safety instructions and the following information:

2.5.1 BATTERIES

WARNING!

- › Improper handling of batteries may result in fire, explosion or other hazards.
 - › The battery fluid can cause personal injury or property damage. If the solution comes into contact with the skin, immediately rinse with plenty of water. If redness, pain or irritation occurs, seek medical attention. If it comes into contact with the eyes, immediately rinse with clean water and seek medical attention..
- Never attempt to open a battery.
 - Do not expose the battery to moisture.
 - Do not expose the battery to heat.
 - Do not store in a place where the temperature may exceed 40 °C.
 - Keep batteries away from children.
 - Charge only at ambient temperatures between 10 °C and 40 °C.

- Only charge the battery with the charger (FBT-CLC011) or the USB-C charging cable included in the package.
- Only use the batteries intended for this purpose in the power tools. The use of other batteries can lead to injury and the risk of fire.
- When disposing of batteries, follow the instructions in the "Disposal" section.
- Do not damage or deform the battery - neither by puncturing nor by hitting it - as this may cause injury and a fire.
- Do not charge damaged batteries.
- Handle the battery with care, do not drop it, or subject it to pressure, other mechanical stress, or extreme heat or cold.
- Warning: risk of accident! Do not short-circuit the battery, never expose it to moisture and do not store it together with metal objects that could short-circuit the contacts. The battery could become very hot, catch fire or explode.
- The battery cells in the battery pack are not replaceable.

Under extreme conditions, battery fluid may leak. If you notice fluid on the batteries, wipe it off carefully with a cloth. Avoid contact with skin. If fluid does come into contact with skin or eyes, follow the instructions below.

2.5.2 CHARGERS

i NOTICE

- » Important! USB charger or quick charger are not included.
- » Recommended charging values: 5.0V d.c. / 1.8 A (Type C).

The charger is designed for a specific voltage. Always check that the mains voltage matches the voltage on the data plate.

⚠ WARNING!

- » When the charger is not in use and before cleaning and maintenance, unplug the charger from the power socket.

- Never replace the charger with a power plug.
- Only use your charger to charge the type of battery included in the delivery. Other batteries may burst and cause property damage and personal injury.
- Never attempt to charge non-rechargeable batteries.
- If the power cord is damaged, it must be replaced by the manufacturer or a service centre in order to avoid a hazard.
- Have damaged cables replaced immediately.
- Never expose the charger to moisture.
- Do not open the charger.
- Do not put your fingers or any objects into the charger.
- Device/tool/battery must be in a well-ventilated place when charging.
- The charger is intended for indoor use only.

2.6 INTENDED USE

This 12V mini air pump is intended exclusively for private users in the hobby and do-it-yourself sector. It is designed for inflating bicycle tires as well as inflatable toys, sports, and beach items.

It is not suitable for large-volume inflatable items, such as inflatable boats or large air mattresses. (Consider a maximum volume of 200 litres / or approximately 10 minutes of continuous operation.)

The device is not suitable for professional use. It is intended exclusively for use by adults.

- Only use the product as described in these instructions. Any other use is considered improper and may result in damage to property or even personal injury.
- Potential injuries due to improper use.
- The manufacturer or dealer accepts no liability for damage caused by improper or incorrect use.

3 SCOPE OF DELIVERY

- 1× Cordless air compressor
- 1× Rechargeable battery
- 1× USB-C charging cable
- 1× 100 mm Hose
- 1× Long air bed nozzle
- 1× Short air bed nozzle
- 1× Ball needle
- 1× Schrader-to-Presta knurled adapter
- 1× Operating instructions

4 PRODUCT OVERVIEW



- 1 Valve connector
- 2 Pressure hose
- 3 ON/OFF Switch
- 4 LED Light

- 5 Union nut
- 6 Ventilation openings
- 7 LCD pressure gauge & battery charge level indicator

- | | | | |
|----|------------------------|----|------------------------------------|
| 8 | Handle | 12 | Short air bed nozzle |
| 9 | Battery release button | 13 | Ball needle |
| 10 | Battery | 14 | Schrader-to-Presta knurled adapter |
| 11 | Long air bed nozzle | | |

5 BEFORE FIRST USE

5.1 CHECK THE PRODUCT AND SCOPE OF DELIVERY

⚠ WARNING! CHOKING HAZARD!

- » Keep all packaging materials away from children and pets - these materials pose a potential hazard, such as choking or swallowing small parts.

CAUTION! RISK OF DAMAGE!

- » Be careful when opening the packaging to avoid damaging the product. Avoid using sharp objects.

- Remove the product from the packaging.
- Remove the packaging material and all plastic/protective films.
- Check whether the delivery is complete (see chapter **SCOPE OF DELIVERY**).
- Check whether the product or its parts are damaged. If this is the case, do not use the product. Contact the service centre using the contact details provided on the front page of this manual.

5.2 BASIC CLEANING

- Before using the product for the first time, clean all parts of the product as described in the **CLEANING AND CARE** chapter.

6 OPERATION

⚠ WARNING!

- » Before assembly, always switch off the machine and remove the battery from the machine.

⚠ WARNING!

- » Improperly attached hoses or accessories can come loose under pressure and cause serious injury.

i NOTICE – HINTS FOR OPTIMUM USE

- » Potential air leaks can lead to incorrect pressure readings. Ensure all connections are tight.

6.1 BATTERY

6.1.1 INSERTING THE BATTERY

Push the charged battery into the battery holder until it clicks into place.

6.1.2 REMOVING THE BATTERY

To remove the battery, press the battery release buttons and pull the battery out. Do not use force when doing so.

6.2 ON/OFF TRIGGER

The tool is switched on and off using the ON/OFF switch **3**.

6.2.1 SWITCHING ON

The tool is switched on by pressing the ON/OFF switch **3**. If the switch is partly pressed, the tool switches off when you release the ON/OFF switch. If you fully press the switch until you feel and hear an audible click, the tool will operate continuously.

6.2.2 SWITCHING OFF

To switch the tool off, briefly press the ON/OFF switch **3**.

6.3 INFLATING A CAR TIRE

Equipped as standard with an air chuck clamp, the mini air pump can be used for inflation, e.g. car tires.

Proceed as follows:

- Insert the battery into the device.
- Position the air chuck clamp **1** in the release position, perpendicular to the air hose.
- Place the inflation nozzle onto the valve stem.
- Press the inflation nozzle downward so that the threaded section of the valve stem is inside the inflation nozzle.
- Clamp the end of the inflation nozzle onto the valve spindle by pressing the air chuck clamp **1** downward to the stop or parallel to the air hose.
- Press the "Set" button (top/centre) on the digital display **7** on the rear of the machine to read the current tire pressure.
- Press the "Set" button again to select the "pressure measuring unit". (You can choose from PSI, BAR, KPA & Kg/cm².)
- Press the "+" or "-" button to set the preset tire pressure to the required tire pressure.
 - (1) Press and hold the "+" or "-" button to adjust the operating pressure quickly. (The set value increases or decreases more quickly.)
 - (2) Briefly press the "+" or "-" button to adjust the preset operating pressure in small increments of 0.05 BAR & kg/cm² or 0.5 PSI, 5 KPA.
- Press the on/off trigger switch **3** to start inflation. When the pressure reaches the preset pressure value, the device stops inflating.

i NOTICE

- » To reset the tire pressure measuring unit, press the "Set" button again to make the selection after setting the preset pressure value.
- » The digital pressure gauge stores the last preset measuring unit and value. After the air pump has reached the preset pressure value, the digital pressure gauge switches off after 60 seconds and the device switches off automatically.

6.4 LED WORK LIGHT

During operation, the LED of the device lights up. This also makes working at night or in dark places easy and convenient. After use, the LED working light and LCD display screen will automatically turn off after being left static for 1 minute, or they can be directly turned off by holding down the SET key.

7 ACCESSORIES

With one of the included accessories, it can be used for a variety of functions.

7.1 INSTALLING / REMOVING AN ACCESSORY

Position the air chuck clamp **1** in the release position.

Insert the rear end of the accessory (air mattress adapter or ball needle) into the opening.

Clamp the end of the inflation nozzle onto the threaded part of the accessory by pressing the chuck clamp **1** downward to the stop or parallel to the air hose.

Air mattress adapter **11** **12**

The air mattress adapter **11** **12** can be used with small pinch valves for inflating small items such as children's toys, which the user would normally have to inflate by blowing air into them.

i NOTICE

- » When inflating items with an air pressure of 0.7 bar (10 psi) or less, always inflate in short bursts. After each burst, check whether the required air pressure has been reached by feeling the item or using a calibrated measuring device.

7.2 NEEDLE ADAPTER FOR (SPORTS) BALLS **13**

The needle adapter for balls is used to inflate sports balls or other items that require inflation via a pointed needle valve.

Moisten the needle with water to facilitate insertion.

Insert the needle adapter **13** into the valve of the sports ball and inflate.

Remove the needle adapter after inflation.

i NOTICE

- » The air pressure required to inflate most sports balls is too low to be accurately read on the device's display.

7.3 TIRE VALVE ADAPTER

Inflating a tire with a Presta valve

- Open the valve locking nut.
- Securely attach the valve adapter **14** to the valve stem with the larger open end facing the tire.
- Open the clamp of the connector nozzle **1** for inflation.
- Clamp the end of the connector nozzle downward onto the valve adapter until the clamp of the connector nozzle **1** is securely seated.
- After inflation, remove the connector nozzle, remove the valve adapter, and securely close the locking nut again.

8 CLEANING AND CARE

8.1 CLEANING

⚠ DANGER! RISK OF ELECTRIC SHOCK!

- » Unplug the product from the power outlet before cleaning.

⚠ WARNING! RISK OF ELECTRIC SHOCK OR SHORT CIRCUIT!

- » Never immerse the product in water or other liquids. Avoid allowing water or other liquids to enter the housing.

⚠ CAUTION! RISK OF SHORT CIRCUIT!

- » Remove the battery from the product before cleaning.

CAUTION! RISK OF DAMAGE!

- » Do not use aggressive cleaning agents, brushes with metal or nylon bristles or sharp or metallic cleaning objects such as knives, hard spatulas and the like. These could damage the surfaces of the product.

8.2 MAINTENANCE AND CARE

⚠ WARNING! RISK OF ELECTRIC SHOCK!

- » Unplug the product before servicing. Any servicing other than that mentioned in this manual should be carried out by a professional repair centre. Contact customer service for servicing.

8.3 STORAGE

CAUTION! RISK OF DAMAGE!

- » Avoid and protect the product from dust, water, moisture, frost, extreme temperatures, high humidity and direct sunlight.

- Before storing, clean all parts as described in the „Cleaning and Care“ chapter.
- Dry the product completely before storing.
- Always store the product in a cool, dry place at an ambient temperature between 5 °C and 20 °C.
- Store the product out of reach of children and pets.

8.4 TRANSPORT

- Protect the product from vibrations or shocks, for example when transporting it in vehicles.
- Secure the product to prevent it from slipping. Use bungee cords, ratchet straps or similar means.

9 TECHNICAL DATA

Rated voltage:	12 V d.c.
Max. air pressure:	100 Psi / 7 Bar
Length of pressure hose:	100 mm
Pressure gauge:	LCD
Weight (without battery):	0.45 kg
Sound pressure level L_{pA} :	87 dB(A)
Uncertainty K_{pA} :	3 dB(A)
Sound power level L_{WA} :	95 dB(A)
Uncertainty K_{WA} :	3 dB(A)

HAND-ARM VIBRATION

Vibration $a_{h,co}$:	2.8 m/s ²
Uncertainty K:	1.5 m/s ²

BATTERY FBT-CLB014

Voltage:	12 V d.c.
Capacity:	2 Ah, 24 Wh
CHARGER FBT-CLC011 (not included in scope of supply)	
Input:	220 – 240 V ~ 50 – 60 Hz, 50 W
Output:	12 V d.c.
Charging current:	2400 mA

10 WASTE DISPOSAL AND RECYCLING

10.1 DISPOSING OF THE PACKAGING

Sort the packaging before you dispose of it. Dispose of paperboard and cardboard with the recycled paper service and wrappings with the appropriate collection service.

The product has been packaged to protect it from damage in transit. The packaging is made of materials that can be recycled in an environmentally friendly manner.

Dispose of the packaging such that it is correctly sorted. Submit cardboard and card to waste paper and foils to the recycling collection.

10.2 DISPOSING OF THE PRODUCT



Old products may not be disposed of in the household waste!

Should the product no longer be capable of being used at some point in time, dispose of it in accordance with the regulations in force in your city or county.

This ensures that old products are recycled in a professional manner and also rules out negative consequences for the environment and human health. For this reason, electrical equipment is marked with the symbol shown here.

10.3 BATTERY DISPOSAL



Batteries may not be disposed of with household waste!

As the end user you are required by law to bring all batteries and rechargeable batteries, regardless whether they contain harmful substances* or not, to a collection point run by the city or county, or to a retailer, so that they can be disposed of in an environmentally friendly manner.

*labeled with: Cd = cadmium, Hg = mercury, Pb = lead

11 EC-DECLARATION OF CONFORMITY

We, the **Batavia B.V., Weth. Wassebaliestraat 6d, NL-7951 SN Staphorst**, hereby declare under our sole responsibility that the product **Cordless air compressor, Type FBT-CAC003**, complies with the essential safety requirements set forth in the European Directives **2006/42/EU** (Machinery), **2014/30/EU** Electromagnetic Compatibility (EMC), **2011/65/EU** (RoHS), **(EU) 2023/1542** and their amendments. The following harmonized standards have been applied for the conformity assessment:

EN 62841-1:2015+A11

EN 1012-1:2010

EN ISO 12100:2010

EN IEC 55014-1:2021

EN IEC 55014-2:2021

EN IEC 63000:2018

EN 62133-2:2017+A1:2021

Staphorst, 12 January 2026

Jin Min, QA Representative

Batavia B.V., Weth. Wassebaliestraat 6d,

7951 SN Staphorst, Netherlands

The product and user manual are subject to change. Specifications are subject to change without notice.

12 UK DECLARATION OF CONFORMITY

We, the **Batavia B.V., Weth. Wassebaliestraat 6d, NL-7951 SN Staphorst, Netherlands** declare by our own responsibility that the product **Cordless air compressor, Type FBT-CAC003**, is according to the basic requirements, which are defined in the UK Regulations: Supply of Machinery (Safety) Regulations 2008, Electromagnetic Compatibility Regulations 2016, Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 and their amendments.

Staphorst, 12 January 2026

Jin Min, QA Representative

Batavia B.V., Weth. Wassebaliestraat 6d,

7951 SN Staphorst, Netherlands

13 WARRANTY

Please contact our **AFTER SALES SUPPORT** by phone or e-mail before sending in the product.

This allows us to provide support in the event of possible operator errors.

13.1 WARRANTY CONDITIONS

Dear Customer,

The **ALDI warranty** offers you extensive benefits:

Warranty period:	3 years from date of purchase. 6 months for wear parts and consumables under normal and proper conditions of use (e.g. rechargeable batteries).
Costs:	Free repair/exchange No transport costs
Hotline:	0 1827 438 013 (GB) 0 124 695 20 (IE) (standard national landline call rate)
Phone lines available:	Mo - Fri 8 am - 6.30 pm

Please contact our **AFTER SALES SUPPORT** by phone or e-mail before sending in the device. This allows us to provide support in the event of possible operator errors.

In order to make a claim under the warranty, please send us:

- The faulty item together with the original purchase receipt
- The product with all components included in the packaging

The warranty does not cover damage caused by:

- **Accident** or **unanticipated events** (e.g. lightning, water, fire)
- **Improper use** or **transport**
- **Disregard of the safety** and **maintenance instructions**
- Other **improper treatment** or **modification** of the product

After the expiry of the warranty period, you still have the possibility to have your product repaired at your own expense. If the repair or the estimate of costs is not free of charge you will be informed accordingly in advance.

This warranty does not affect your statutory rights. In the event that a product is received for repair, neither the service company nor the seller will assume any liability for data or settings possibly stored on the product by the customer.





**PRODUCED IN
CHINA FOR** **ALDI STORES LTD.**
PO Box 26,
ATHERSTONE,
WARWICKSHIRE,
CV9 2SH

ALDI STORES (IRELAND) LTD.
PO Box 726,
NAAS,
CO. KILDARE
VISIT US AT WWW.ALDI.COM

MADE IN CHINA

V01/0126